



Use this chart to determine which KLEENGUARD* Brand Eye Protection is right for you.

KLEENGUARD* Eye Protection	Lens Style					Protection Feature					Comfort Feature				
	Clear	Smoke	Clear, Anti-Fog	Indoor/Outdoor	OTG, Clear	Impact Resistant	Wraparound Lens	Adjustable Lens Angle	ANSI Z87.1+	99% UV/UVB Protection	Lightweight Frames	Ratcheted Temples	Padded Temples	Padded Nose Bridge	Cushioned Brow Bar
V10 Standard	X	X			X	X		X	X	X					
V20 Comfort	X	X	X	X		X	X		X	X		X			
V30 Flexible	X	X	X	X		X	X	X	X	X	X	X	X		
V40 Contour	X	X	X	X		X	X		X	X		X	X	X	

† Except OTG (Over-the-glass)

KLEENGUARD* Brand Eye Protection:

- Provides limited eye protection. Additional protective devices are required for full eye coverage and protection.
- Does not protect you from all hazards. Even though the lenses in these safety glasses are impact resistant, they can break and shatter and will not protect you from explosions, all flying debris, and severe impacts.
- Should not be worn to provide protection from other hazards including, but not limited to, extreme temperatures, high heat, airborne dusts or mists, liquid splashes, sports activities and high energy optical radiation.

MEETS THE HIGH IMPACT REQUIREMENTS IN ANSI Z87.1+



Kimberly-Clark Trading (M) Sdn Bhd

9th & 10th Floor, Tower 2, Kelana Brem Tower,
Jln SS7/15 (Jln Stadium), Kelana Jaya, 47301
Petaling Jaya, Selangor Darul Ehsan, Malaysia.
Toll Free : 1800 899 466
Tel : (03) 7803 2212
Fax : (03) 7492 2576
E-mail : kcp.mktsg@kcc.com

Kimberly-Clark Singapore Pte Ltd

3 Anson Road, # 16-01, Springleaf Tower,
Singapore 079909
Toll Free : 1800 562 5275
Tel : (65) 6226 2882
Fax : (65) 6327 3857
E-mail : kcp.mktsg@kcc.com

Visit our online safety tools:

Safety Knowledge Network
www.kc-safety.com



See the difference

Comfort & Style can make in eye protection



INTRODUCING...
KLEENGUARD* Brand Eye Protection –
More comfort, more acceptance,
more style, more compliance.
Now that's a winning proposition!

©/* Registered Trademark or Trademark of Kimberly-Clark Worldwide, Inc.
© 2008 KCWW. All Rights Reserved.



Sometimes the only thing standing between you and a serious industrial accident is your eye protection. That's why you need KLEENGUARD* Brand Eye Protection. Plus, with all the added features for comfort and flexibility, it's easy to see why more workers wear it for protection and want it for comfort, flexibility and style.

Proven Impact Protection

KLEENGUARD* Eyewear Protection offers a variety of options that meet ANSI Z87.1+ standards.

Added Comfort and Flexibility

Our state-of-the-art eyewear design includes wrap-a-round lenses, flexible temples, padded nose bridges and other features to enhance your comfort and job performance.

Wide Selection of Lens Types

Choose the lens type that best meets your individual work requirements and style preferences.

Clear - Choose this lens for maximum visible light transmission; ideal for indoor applications.

Clear, Anti-fog - Choose this lens to help prevent fogging in high-humidity environments or when temperature shifts happen rapidly.

Smoke - Choose this lens for bright, sunny days for maximum glare reduction. Ideal for applications where eyestrain is a concern.

Indoor/Outdoor - Light tinting for moving comfortably between indoor/shaded areas to direct sunlight and back.



KleenGuard
Standard Eye Protection **V10**



Features:

- Impact resistant Polycarbonate lens
- Lightweight "wrap-a-round" design for added comfort and coverage
- 99.9% UVA/UVB protection
- Over the glass (OTG) visitors option available

KLEENGUARD* V10 Standard Eye Protection

KleenGuard V10 Standard Eye Protection

KCP Code	Colour	Pairs/Box	Boxes/Case	Pairs/Case
08582	Clear	12	24	288
08585	OTG, Clear	12	21	252

KleenGuard
Comfort Eye Protection **V20**



Features:

- Impact resistant Polycarbonate lens
- Lightweight "wrap-a-round" design for added comfort and coverage
- 99.9% UVA/UVB protection
- Comfortable padded temples

KLEENGUARD* V20 Comfort Eye Protection

KleenGuard V20 Comfort Eye Protection

KCP Code	Colour	Pairs/Box	Boxes/Case	Pairs/Case
08589	Clear, Anti-Fog	12	24	288

KleenGuard
Flexible Eye Protection **V30**



Features:

- Impact resistant Polycarbonate lens
- Lightweight "wrap-a-round" design for added comfort and coverage
- 99.9% UVA/UVB protection
- Angling soft rubber temples
- Comfortable padded nose bridge
- Ratcheting temples for better fit

KLEENGUARD* V30 Flexible Eye Protection

KleenGuard V30 Flexible Eye Protection

KCP Code	Colour	Pairs/Box	Boxes/Case	Pairs/Case
08452	Clear, Anti-Fog	12	24	288

KleenGuard
Contour Eye Protection **V40**



Features:

- Impact resistant Polycarbonate lens
- Lightweight "wrap-a-round" design for added comfort and coverage
- 99.9% UVA/UVB protection
- Comfortable dual-moulded rubber temples
- Soft adjustable nose bridge
- Cushioned brow bar for additional comfort and ventilation

KLEENGUARD* V40 Contour Eye Protection

KleenGuard V40 Contour Eye Protection

KCP Code	Colour	Pairs/Box	Boxes/Case	Pairs/Case
08458	Clear, Anti-Fog	12	24	288